Lab 5-Module 5.4: QPhotoRec

Objectives

• File carving using PhotoRec

Task

Task 1. Software Preparation

Image included:

- Lake.png
- Fun.bmp
- testpdf.pdf
- text.txt

You may choose CAINE or Windows to perform this lab.

CAINE:

CAINE has pre-installed PhotoRec. No additional download needed.

Windows:

- Download PhotoRec from the official website: https://www.cgsecurity.org/wiki/TestDisk Download, then unzip the folder to desktop
- 2. Download the image and put it on desktop
- 3. Create a folder on desktop called "photoRecOutput" to store the recover files




4. Open testdisk folder and open qphotorec_win.exe


(Note: photorec_win.exe is the command line application and qphotorec is the GUI application)




Task 2: File carving using PhotoRec




1. Click select a media to recover from and select "Add a raw disk image..."



2. Select the image we prepared in step 2 and then click "Open"




3. Select the item that has Flags P(which stand for petition) and the File System is NTFS




4. Select FAT/NTFS/HFS+/ReiserFS/... and select Free: Scan for file from unallocated space only




5. For the destination, click **browse** and select the folder we created in step 3.



6. Click on File Formats and you can check all the file formats which photoRec supports.



7. Keep the default setting and click OK, then click Search to start the data recovery process. The process may take some time but should not be longer than 3 mins



8. After it is finished, it will list the file type that has successfully recovered and the number of files. Click "Quit" to exit the application.



9. Open "photoRecOutput" folder on desktop and

Question:

- 1. How many files does photoRec successfully recover?
- 2. Which file format does photoRec **cannot** be recovered?